

Putting Water Where it Counts![®]



Sprinkler Accessories

Made in Australia

antelco.com

Sprinkler Accessories

A range of accessories to install Rotor Rain[®], Rotor Max[™], and other industry standard 3/8" threaded micro sprinklers.



Sprinkler Adaptor

Perfect for suspended trellis wire installations, the sprinkler adaptor is available in 5 mm, 10 mm, and 13 mm barb sizes, or pre-assembled with 4 mm ID tube in 600 mm, 900 mm, and 1200 mm tube lengths.



Rotor Stake[™]

Rotor Stake[™] is designed for securing 3/8" threaded micro mini sprinklers. The stake includes a retaining hole to keep tube firmly in place near the stake. The tube piercing point allows for hole punch installation.



Rod Stake Sprinkler Adaptor

Ideal for 5 mm OD fibreglass or steel rod applications, available in 5 mm and 10 mm barb sizes.

Collar Pipe Sprinkler Adaptor

Designed for 20 mm uPVC or Galvanised riser installations (26.7 mm OD), this adaptor is available in 5 mm, 10 mm, and 13 mm barb sizes.



Socket Driver for Rotor Rain[®] Plus

Using a low speed torque controlled drill, simply slip the aluminium Socket Driver over sprinkler heads for easy installation into threaded stakes and risers.


Ordering Information - Installation Tool

Description	Order Code	Pack Quantity	Packs Per Carton	Carton (kg)
Socket Driver for Rotor Rain® Plus	51905	1	180	17.2



Ordering Information - Rotor Stake™ 3/8" BSPF

Type	Order Code	Pack Quantity	Packs Per Carton	Carton (kg)
Rotor Stake™ 3/8" BSPF x 5 mm barb	40555	25	6	5.1
Rotor Stake™ 3/8" BSPF x 10 mm barb	40515	25	6	5.2
Rotor Stake™ 3/8" BSPF x 13 mm barb	40535	25	6	5.3
Rotor Stake™ 3/8" BSPF with 600 mm tube & self piercing adaptor	40675	25	4	5.9
Rotor Stake™ 3/8" BSPF with 900 mm tube & self piercing adaptor	40685	25	4	6.9
Rotor Stake™ 3/8" BSPF with 1200 mm tube & self piercing adaptor	40695	25	3	6.0



Ordering Information - Sprinkler Adaptor 3/8" BSPF

Description	Order Code	Pack Quantity	Packs Per Carton	Carton (kg)
Sprinkler Adaptor 3/8" BSPF x 5 mm barb	40755	50	40	6.8
Sprinkler Adaptor 3/8" BSPF x 10 mm barb	40715	50	34	6.7
Sprinkler Adaptor 3/8" BSPF x 13 mm barb	40735	50	30	6.2



Ordering Information - Collar Pipe Sprinkler Adaptor 3/8" BSPF

Type	Order Code	Pack Quantity	Packs Per Carton	Carton (kg)
Collar Pipe Sprinkler Adaptor x 5 mm barb	40655	50	10	5.5
Collar Pipe Sprinkler Adaptor x 10 mm barb	40615	50	10	5.6
Collar Pipe Sprinkler Adaptor x 13 mm barb	40635	50	10	5.8




Ordering Information - Rod Stake Sprinkler Adaptor 3/8" BSPF

Type	Order Code	Pack Quantity	Packs Per Carton	Carton (kg)
Rod Stake Sprinkler Adaptor 3/8" BSPF x 5 mm barb	40815	50	35	7.1
Rod Stake Sprinkler Adaptor 3/8" BSPF x 10 mm barb	40855	50	24	5.6



Ordering Information - Sprinkler Adaptor Assembly with Tube & Adaptor

Type	Order Code	Pack Quantity	Packs Per Carton	Carton (kg)
Sprinkler Adaptor Assembly 3/8" BSPF with 600 mm tube	43195	25	12	8.1
Sprinkler Adaptor Assembly 3/8" BSPF with 900 mm tube	43205	25	8	9.2
Sprinkler Adaptor Assembly 3/8" BSPF with 1200 mm tube	43215	25	8	9.5



Antelco Group of Companies

LINCOLN
— Est. 1959 —
MOULDING THE FUTURE

ANTELCO®

Dawn



Antelco Australia
Antelco Pty Ltd ABN 50 008 062 708
Sales & Marketing,
Orders & Warehouse
Research & Development
PO Box 95, 131 Tolley Rd,
St Agnes SA 5097 Australia
+61 8 8334 4333
adelaide@antelco.com.au

Antelco USA
Antelco Corporation
Sales & Marketing,
Orders & Warehouse
886 Waterway Pl,
Longwood,
Florida 32750 USA
+1 407 331 0699
info@antelco.com

Antelco Europe
Antelco UK Limited
Sales & Marketing,
Orders & Warehouse
17a Chartmoor Rd,
Leighton Buzzard,
Bedfordshire LU7 4WG UK
+44 152 585 9990
orders@antelco.co.uk