

Antelco Group of Companies

LINCOLN  
Est. 1959  
MOULDING THE FUTURE

ANTELCO®

Dawn

Putting Water Where it Counts!®



Antelco Australia  
Antelco Pty Ltd ABN 50 008 062 708  
Sales & Marketing,  
Orders & Warehouse  
Research & Development  
PO Box 95, 131 Tolley Rd,  
St Agnes SA 5097 Australia  
+61 8 8334 4333  
adelaide@antelco.com.au

Antelco USA  
Antelco Corporation  
Sales & Marketing,  
Orders & Warehouse  
886 Waterway Pl,  
Longwood,  
Florida 32750 USA  
+1 407 331 0699  
info@antelco.com

Antelco Europe  
Antelco UK Limited  
Sales & Marketing,  
Orders & Warehouse  
17a Chartmoor Rd,  
Leighton Buzzard,  
Bedfordshire LU7 4WG UK  
+44 152 585 9990  
orders@antelco.co.uk

# Sprinkler Accessories

antelco.com

# Sprinkler Accessories

A range of accessories to install Rotor Rain™, and other industry standard 3/8" threaded micro sprinklers.



### Sprinkler Adapter

Perfect for suspended trellis wire installations, this adapter comes in 5 mm, 10 mm, and 13 mm barb sizes.



### Rotor Stake™

Rotor Stake™ is designed for securing 3/8" threaded micro mini sprinklers. The stake includes a retaining hole to keep tube firmly in place near the stake. The tube piercing point allows for hole punch installation.



### Rod Stake Sprinkler Adapter

Ideal for 0.2" (5 mm) OD fibreglass or steel rod applications, available in 5 mm and 10 mm barb sizes.



### Collar Pipe Sprinkler Adapter

Designed for 1.0" OD uPVC or Galvanized riser installations (26.7 mm OD), this adapter is available in 5 mm, 10 mm, and 13 mm barb sizes.



### Rotor Rain™ Plus Socket Driver

Using a low speed torque controlled drill, simply slip the aluminium Socket Driver over sprinkler heads for easy installation into threaded stakes and risers.

## Sprinklers Accessories

### Ordering Information - Installation Tool

Description	Part Number	Pack Quantity	Packs Per Carton	Carton (lbs)
Socket Driver for Rotor Rain™ Plus	51905	1	180	37.9

### Ordering Information - Rotor Stake™ 3/8" Female Thread

Type	Part Number	Pack Quantity	Packs Per Carton	Carton (lbs)
Rotor Stake™ x 5 mm barb adapter	40555	25	6	11.2
Rotor Stake™ x 10 mm barb adapter	40515	25	6	11.4
Rotor Stake™ x 13 mm barb adapter	40535	25	6	11.7
Rotor Stake™ x 24" (5mm) tube & 0.16" barb Self Piercing Adapter	50695	15	6	11.7

### Ordering Information - Sprinkler Adapter 3/8" Female Thread

Description	Part Number	Pack Quantity	Packs Per Carton	Carton (lbs)
Sprinkler Adapter 3/8" Female Thread x 5 mm	40755	50	40	15.0
Sprinkler Adapter 3/8" Female Thread x 10 mm	40715	50	34	14.7
Sprinkler Adapter 3/8" Female Thread x 13 mm	40735	50	30	13.6

### Ordering Information - Collar Pipe Sprinkler Adapter 3/8" Female Thread


Type	Part Number	Pack Quantity	Packs Per Carton	Carton (lbs)
Collar Pipe Sprinkler Adapter x 5 mm barb	40655	50	10	12.1
Collar Pipe Sprinkler Adapter x 10 mm barb	40615	50	10	12.3
Collar Pipe Sprinkler Adapter x 13 mm barb	40635	50	10	12.8

### Ordering Information - Rod Stake Sprinkler Adapter 3/8" Female Thread

Type	Part Number	Pack Quantity	Packs Per Carton	Carton (lbs)
Rod Stake Sprinkler Adapter 3/8" Female Thread x 5 mm barb	40815	50	35	15.6
Rod Stake Sprinkler Adapter 3/8" Female Thread x 10 mm barb	40855	50	24	12.3



Socket Driver for Rotor Rain™ Plus



Rotor Stake™

Rotor Stake™ with Tube and Self Piercing Adapter



Sprinkler Adapter



Collar Pipe Sprinkler Adapter



Rod Stake Sprinkler Adapter